


SERIE NARDI

ES INSTRUCCIONES DE MONTAJE
GB INSTALLATION INSTRUCTIONS

FR INSTRUCTIONS D'INSTALLATION
DE MONTAGEANLEITUNG

ESQUEMA/SCHEME/SCHÉMA/SCHEMA



SERIE NARDI

13

a

2cm

04

b

c

$\phi 6.0\text{mm}$

d

06

e

09

Ancho	(NA 600)	(NA 600)
71,5-74,5	40	40
76,5-79,5	40	45
81,5-84,5	45	45
86,5-89,5	45	50
91,5-94,5	50	50
96,5-99,5	50	55
101,5-104,5	55	55
106,5-109,5	55	60
111,5-114,5	60	60
116,5-119,5	60	65
121,5-124,5	65	65
126,5-129,5	65	70
131,5-134,5	70	70
136,5-139,5	70	75
141,5-144,5	75	75
146,5-149,5	75	80
151,5-154,5	80	80

2.6 5 2.8 NA 600 2 (NA 606) 5 2.8

14

a

07

11

01

41

b

40

12

c

01

39

d

47

e

0-1.5cm

04

f

0-1.5cm

04

g

12

23


24

12

h

47

15



16

